

MINOX - Accessories

For Picture Taking: MINOX Exposure Meter - MINOX Camera Clamps for attaching to Tripod etc. - MINOX Table Tripod - MINOX Binocular Clamp - MINOX Copying Arm - MINOX Universal Copying Arm - MINOX Folding Reproduction Stand - MINOX Black and white films for all purposes and all degrees of sensitivity - MINOX Color film.

For Film Developing: MINOX Daylight Developing Tank - MINOX Fine Grain Developer - MINOX Transparent Negative Wallets.

For Enlarging: MINOX Enlarger Copying Stand Modell II - MINOX Enlarger Easel with Print Mask MINOX Film Magnifier.

For Projection: MINOX Projector - MINOX Slide Frames - MINOX Film Cutter.

This complete line of intelligently designed and very practical accessories add to the scope of MINOX photography. They will be welcomed particularly by those photographers who want to utilize the many special applications to which the MINOX can be put, or who want to do their own developing and enlarging.

MINOX G. m. b. H., Optical and Precision Engineering Works
Giessen, P. O. B. 137, Germany

417 e

Printed in Germany


IX, 56



MINOX Finder Mirror

Candid Photography

MINOX Reflex Finder



MINOX Finder Mirror

True-to-life, candid snapshots are a particular specialty of the tiny, unobtrusive MINOX. But, you will hardly be noticed as a "snaphooter" if you aim away from the subject and take the snapshots "around the corner".

That is the purpose of the MINOX Finder Mirror.

Slide the cap of the Finder Mirror over the flash end of your MINOX (1) so that the silver-surfaced mirror is next to the camera finder eyepiece (2). Two springs will grip the camera housing.

While your MINOX points to the right at the subject, you stand at a right angle to the line of vision, observing the subject through the mirror.

Take a look at the young lady at the top of the previous page. Do you know whose picture she is taking? - YOURS!

By the way, notice how she holds the camera for shooting "around the corner" without covering the lens window.


That's the correct way.

MINOX Reflex Finder

While the Finder Mirror is especially useful for candid vertical shots "around the corner", the MINOX Reflex Finder permits equally candid shooting from waist level for horizontal pictures.

The Reflex Finder is slipped on the camera just like the Finder Mirror (3 and 4). Holding your camera at waist level - as shown on the front page - you can see your subject clearly in the large rectangular lens of the Reflex Finder. You can see the finder image even if you don't look straight down - quite an advantage!

But remember to hold your MINOX so that your fingers do not cover the camera lens window. Why not try it out in front of a mirror before you really start snaphooting.



Auf dem linken Bild sehen Sie die MINOX B mit dem aufgesteckten Sucherspiegel. Bitte achten Sie darauf, daß das Zeitfenster des Belichtungsmessers immer vollständig zu sehen ist, sonst stimmt die Messung nicht mehr. Das rechte Bild zeigt den auf die MINOX A aufgesteckten Sucherspiegel.

Im Bild 6 ist der Aufsichtssucher auf die MINOX B, im Bild 8 auf die MINOX A aufgesteckt. Sie erkennen deutlich, daß die beiden "Fenster" des Aufsichtssuchers in gleicher Fortsetzung der Camera-Vorderseite und der Camera-Oberseite stehen müssen.



MINOX-Sucherspiegel

. . . . unbemerkt photographieren

MINOX-Aufsichtssucher



MINOX G. m. b. H., Optische und Feinmechanische Werke
63 Giessen 1, Postfach 137

417 d

Änderungen vorbehalten
Printed in Germany

15/63



MINOX-Sucherspiegel

Die lustigsten, aber auch interessantesten Aufnahmen sind unbemerkt fotografierte Schnappschüsse. Die kleine, unauffällige MINOX ist dazu besonders gut geeignet. Sie sind jedoch kaum als Schnappschütze zu entdecken, wenn Sie „um die Ecke“ fotografieren.

Und das erreichen Sie mit dem MINOX-Sucherspiegel. Bei der MINOX A (Abb. 1) wird er auf die Schmalseite, die den Synchronkontakt trägt, bei der MINOX B (Abb. 2) auf den eingebauten Belichtungsmesser aufgesteckt. Ein oberflächenversilberter Spiegel sitzt dann vor dem Sucherfenster (Abb. 5 und 7). Während Ihre MINOX auf das Objekt gerichtet ist, stehen Sie im rechten Winkel zur Aufnahmerichtung und beobachten das Sucherbild im Spiegel. Schauen Sie sich bitte die junge Dame in dem Bild auf der Titelseite rechts oben einmal an. Wissen Sie, wen Sie gerade fotografiert? - Sie!

Auf diesem Bild erkennen Sie aber noch etwas anderes: Wie man die MINOX beim „Um-die-Ecke-Fotografieren“ richtig hält, ohne das Objektivfenster zu verdecken.

Und das ist wichtig!

MINOX-Aufsichtssucher


Während man mit dem Sucherspiegel Hochformataufnahmen „um die Ecke“ schießt, erhält man mit dem MINOX-Aufsichtssucher ebenso unbemerkte Querformat-Schnappschüsse aus Hüfthöhe.

Der Aufsichtssucher wird wie der Sucherspiegel auf die MINOX aufgesteckt (Abb. 3 MINOX A, Abb. 4 MINOX B). Wenn Sie nun die Camera in Gürtelhöhe halten, sehen Sie in der großen rechteckigen Linse des Aufsichtssuchers das helle, klare Sucherbild (so wie die Dame auf dem unteren Titelseiten-Bild in ihrem Aufsichtssucher gerade Sie betrachtet). Sie sehen das Sucherbild auch dann, wenn Sie nicht gerade haargenau senkrecht in die Linse blicken - ein nicht unwesentlicher Vorzug.

Achten Sie aber bitte auch beim Aufsichtssucher darauf, daß kein Finger Ihrer rechten Hand das Objektivfenster verdeckt. Vielleicht prüfen Sie Ihre Camerahaltung erst im Spiegel, bevor Sie auf Schnappschußjagd gehen.




MINOX



Sucherspiegel
Right Angle Finder
Viseur d'angle
Espejo visor
Zoekerspiegel
Mirino a specchio

MINOX GmbH.
63 Gießen 1 · Postfach 6020

436 Printed in Germany



Objektivfenster nicht mit einem Finger verdecken.

Do not obstruct lens window with fingers.

Ne pas obturer la fenêtre de l'objectif avec le doigt.

No cubran con un dedo la ventanilla del objetivo.

Objectief venster niet met uw vinger bedekken.

Non coprire la finestrella dell'obiettivo con un dito.

Não tapar a janela da objectiva com o dedo.

Täck inte objektivfönstret med fingrarna.

